filt.

FILTER REPLACEMENT GUIDE

Replace the filters yourself in about 10 minutes


Komfovent Domekt R 200 V • left-hand version (L1)

1 × F7 filter
blows fresh air into the room

1 × M5 filter
draws room air out


285×130×46 mm
size of both filters

1 Where are the filters?



Unit seen from the front, door open. The coloured arrows show how the air moves: from the duct at the top, down through the filter into the unit.

2 Most important: the arrow on the filter



**In this unit the air moves from the top down.
So the arrow on the filter must point DOWN ↓**

Each filter has an arrow on its frame. The arrow shows which way the air goes through the filter. A filter fitted the wrong way round does not clean the air properly.

Komfovent Domekt R 200 V, L1 • Drawing: manufacturer's technical sheet, p. 25
Filter size 285×130×46 mm

filt.

3 Right way and wrong way



Right
Arrow points down, into the unit



Wrong
Arrow points up, filter upside down

4 Replacing the filters step by step

1 Switch the unit off

Switch the unit off at the control panel and disconnect it from the mains. Wait until the fans have stopped.

2 Open the front door

The filters are behind the door in the top of the unit, side by side in the middle.

3 Take out the old filters

Pull both filters out towards you. The left one is the F7, the right one the M5.

4 Find the arrow on the new filter

There is an arrow on the filter frame. Turn the filter so that the arrow points DOWN.

5 Slide the new filters in

F7 on the left, M5 on the right. Push them all the way in, arrows still pointing down.

6 Close the door and switch on

If the panel shows a filter warning, reset it. Done!

How often to replace?
Usually every 6 months, or when the control panel shows a filter warning.

Right-hand unit (R1)?
Then the filters are mirrored: F7 on the right and M5 on the left. The arrow still points down.

Anything unclear?
Contact us and we will help you find the right filter: filt.ee

Old filter
Put it in a plastic bag and dispose of it with household waste.